CERN Courier – digital edition

Welcome to the digital edition of the May/June 2023 issue of CERN Courier.

Meet "the python" – one of eight 60 m-long high-temperature superconducting links to power new magnets for the High-Luminosity LHC. Developed at CERN via a multi-disciplinary approach and in collaboration with industry, the technology has also been used to demonstrate record power-transmission capability for electricity grids, and is being explored for use in electric aircraft.

This year's Recontres de Moriond saw the announcement of the first collider neutrinos (p9), improved measurements of the W mass (p10), new limits on Majorana neutrinos (p9), ever tighter constraints on the properties of dark matter (p15), and much more. While the Standard Model stands strong, ingenious new ways to go beyond it include searches at CERN's NA62 experiment operating in "beam-dump" mode (p11). This issue also marks 60 years since Cabibbo's seminal paper on quark mixing (p43), and 50 years since Kobayashi and Maskawa generalised the description of quark mixing to three generations (p23).

Muons for cultural heritage (p32) and colliders (p47), a new user facility for plasma acceleration (p25), CERN's Science Gateway (p49) and "exotic naturalness" (p21) are further highlights, as high-energy collisions recommence at LHC Run 3 (p8).

To sign up to the new-issue alert, please visit: http://comms.iop.org/k/iop/cerncourier

To subscribe to the magazine, please visit: https://cerncourier.com/p/about-cern-courier

CERNCOURIER

HIGH-T_C SUPERCONDUCTING LINKS FOR HL-LHC

IOP Publishing

Muons for cultural heritage • No time to wait for a future collider • Moriond results galore

EDITOR: MATTHEW CHALMERS, CERN DIGITAL EDITION CREATED BY IOP PUBLISHING

(

lav/Iune 2023 cerncourier.c

VOLUME 63 NUMBER 3 MAY/JUNE 2023







Magnets and coils

High quality magnets and coils, designed and manufactured by Swedish engineering in order to provide the best solutions for all your needs! We take pride in close collaborations with the customer, whether it is for research or industry

Product Applications

Magnetic Resonance Imaging

Nuclear Magnetic Resonance

High Energy Physics

SC Magnetic Energy Storage

Medical Therapeutic Devices

Superconducting Magnets and Coils

Crystal Growth Magnets

Scientific Projects

 $(\bigstar) (\leftarrow)$

 (\rightarrow)

SUPERCON, Inc. **Superconducting Wire Products**

Standard and Speciality designs are available to meet your most demanding superconductor requirements.

SUPERCON, Inc. has been producing niobium-based superconducting wires and cables for 58 years. We are the original SUPERCON – the world's first commercial producer of niobium-alloy based wire and cable for superconducting applications.

Standard SC Wire Types

NbTi Wires Nb₃Sn —Bronze Nb₃Sn —Internal Tin CuNi resistive matrix wires Fine diameter SC Wires Aluminum clad wire Wire-in-Channel Innovative composite wires

>SCANDITRONIX-MAGNET.SE

"We deliver when you need us!"

www.SUPERCON-WIRE.com

NEW SUPERCONDUCTING TECHNOLOGIES FOR THE HL-LHC AND BEYOND

The development at CERN of magnesium diboride cables and other advanced superconducting systems for the High-Luminosity LHC is also driving applications beyond fundamental research, describes Amalia Ballarino.

he era of high-temperature superconductivity started in 1986 with the discovery, by IBM researchers Georg Bednorz and Alex Muller, of superconductivity in a lanthanum barium copper oxide. This discovery was revolutionary: not only did the new, brittle superconducting compound belong to the family of ceramic oxides, which are generally insulators, but it had the highest critical temperature ever recorded (up to 35 K, compared with about 18 K in conventional superconductors). In the following years, scientists discovered other cuprate superconductors (bismuth-strontium-copper oxide and yttrium-bariumcopper oxide) and achieved superconductivity at temperatures above 77 K, the boiling point of liquid nitrogen (see "Heat is rising" figure, p38). The possibility of operating superconducting systems with inexpensive, abundant and inert liquid nitrogen generated tremendous enthusiasm in the superconducting community.

Several applications of high-temperature superconducting materials with a potentially high impact on society were studied. Among them, superconducting transmission lines were identified as an innovative and effective solution for bulk power transmission. The unique advantages of superconducting transmission are high capacity, very compact volume and low losses. This enables the sustainable transfer of up to tens of GW of power at low and medium voltages in narrow channels, together with energy savings. Demonstrators have been built worldwide in conjunction of current, generated at room temperature, in and out of with industry and utility companies, some of which have the cryogenic environment. This is done via devices called successfully operated in national electricity grids. However, current leads, of which more than 3000 units are installed widespread adoption of the technology has been hindered at different underground locations around the LHC's cirby the cost of cuprate superconductors.

materials, with applications stretching far beyond fundamental research.

CERN COURIER MAY/IUNE 2023

Link to the future Tests at CERN of a full -scale 120 kA MqB, -based superconducting link "Demo 3", colloquially known as the "python", for the High-Luminosity LHC.

High-temperature superconductivity (HTS) was discovered at the time when the conceptual study for the LHC was ongoing. While the new materials were still in a development phase, the potential of HTS for use in electrical transmission was immediately recognised. The powering of the LHC magnets (which are based on the conventional superconductor niobium titanium, cooled by superfluid helium) requires the transfer of about 3.4MA cumference. The conventional current-lead design, based In particle physics, superconducting magnets allow on vapour-cooled metallic conductors, imposes a lower high-energy beams to circulate in colliders and provide limit (about 1.1W/kA) on the heat in-leak into the liquid stronger fields for detectors to be able to handle higher helium. The adoption of the HTS BSCCO 2223 (bismuthcollision energies. The LHC is the largest supercon-strontium-calcium copper oxide ceramic) tape - operated ducting machine ever built, and the first to also employ in the LHC current leads in the temperature range 4.5 to high-temperature superconductors at scale. Realising its 50 K - enabled thermal conduction and ohmic dissipation high-luminosity upgrade and possible future colliders to be disentangled. Successful multi-disciplinary R&D folis driving the use of next-generation superconducting lowed by prototyping at CERN and then industrialisation, with series production of the approximately 1100 LHC HTS superconductors and

THE AUTHOR Amalia Ballarino deputy leader of CERN's magnets, current leads starting in 2004, resulted in both capital cryostats group.

IOP Publishing

37

CERNCOURIER VOLUME 63 NUMBER 3 MAY/JUNE 2023

FEATURE SUPERCONDUCTIVITY

Heat is rising Critical temperature of superconductors versus year of discovery, with cuprate superconductors shown in green. Fe SC stands for iron-based superconductors.

Complex cabling Left: a 1 mm diameter MqB, round wire; centre: a MqB, round cable, about 7 mm in diameter, capable of carrying a 3 kA current at a temperature of 25K in a magnetic field of 0.7 T; right: a coaxial MgB₂ cable, capable of carrying 3 kA at 25 K.

> and operational savings (avoiding one extra cryoplant and an economy of about 5000 l/h of liquid helium). It also encouraged wider adoption of BSCCO 2223 current-lead technology, for instance in the magnet circuits for the ITER MRI systems for transporting currents of a few hundred tokamak, which benefit via a collaboration agreement with amperes. The requirement for the HL-LHC to transfer current CERN on the development and design of HTS current leads. to multiple circuits for a total of up to 120 kA in a compact

MgB, links at the HL-LHC

(MgB₂) in 2001 generated new enthusiasm for HTS applications. This material, classified as medium-temperature superconductor, has remarkable features: it has a critical temperature (39 K) some 30 K higher than that of niobium titanium, a high current density (to date in low and medium from the surrounding nickel and avoid the formation of brittle magnetic fields) and, crucially, it can be industrially produced as round multi-filamentary wire in long (km) lengths. These characteristics, along with a cost that is intrinsically lower than other available HTS materials, make it a promising candidate for electrical applications.

straight sections. For the high-luminosity upgrade of the (about 55 µm) and twist pitch (about 100 mm) for the benefit of LHC (HL-LHC), scheduled to be operational in 2029, the electro-mechanical properties; the addition of a copper stadecision was taken to locate the power converters in new, biliser around the Monel matrix; and the coating of tin-silver radiation-free underground technical galleries above the onto the copper to ensure the surface quality of the wire and LHC tunnel. The distance between the power converters a controlled electrical resistance among wires (inter-strand and the HL-LHC magnets spans about 100 m and includes a resistance) when assembled into cables. After successive vertical path via an 8 m shaft connecting the technical gal- implementation and in-depth experimental validation of leries and the LHC tunnel. The large current to be transferred all improvements, a robust 1mm-diameter MgB₂ wire with

across such distance, the need for compactness, and the search for energy efficiency and potential savings led to the selection of HTS transmission as the enabling technology. The electrical connection, at cryogenic temperature, between the HL-LHC current leads and the magnets is performed via superconducting links based on MgB2 technology. MgB2 wire is assembled in cables with different layouts to transfer currents ranging from 0.6 kA to 18 kA. The individual cables are then arranged in a compact assembly that constitutes the final cable feeding the magnet circuits of either the HL-LHC inner triplets (a series of quadrupole magnets that provides the final focusing of the proton beams before collision in ATLAS and CMS) or the HL-LHC matching sections (which match the optics in the arcs to those at the entrance of the final-focus quadrupoles), and the final cable is incorporated in a flexible cryostat with an external diameter of up to 220 mm. The eight HL-LHC superconducting links are about 100 m long and transfer currents of about 120 kA for the triplets and 50 kA for the matching sections at temperatures up to 25K, with cryogenic cooling performed with helium gas.

The R&D programme for the HL-LHC superconducting links started in around 2010 with the evaluation of the MgB₂ conductor and the development, with industry, of a round wire with mechanical properties enabling cabling after reaction. Brittle superconductors, such as Nb₃Sn – used in the HL-LHC quadrupoles and also under study for future high-field magnets - need to be reacted into the superconducting phase via heat treatments, at high temperatures, performed after their assembly in the final configuration. In other words, those conductors are not superconducting until cabling and winding have been performed. When the R&D programme was initiated, industrial MgB, conductor existed in the form of multi-filamentary tape, which was successfully used by ASG Superconductors in industrial open configuration, with multiple twisting and transposition steps necessary to provide uniform current distribution The discovery of superconductivity in magnesium diboride in both the wires and cables, called for the development of an optimised multi-filamentary round wire.

> Carried out in conjunction with ASG Superconductors, this development led to the introduction of thin niobium barriers around the MgB₂ superconducting filaments to separate MgB₂ MgB₂-Ni reaction layers that compromise electro-mechanical performance; the adoption of higher purity boron powder to increase current capability; the optimisation in the fraction of Monel (a nickel-copper alloy used as the main constituent of the wire) in the 1mm-diameter wire to improve

At the LHC the current leads are located in the eight mechanical properties; the minimisation of filament size

Bridging the gap Shown on the left is a longitudinal cross-section of 4 mm-wide REBCO tape, pictured from a different perspective in the middle panel, and on the right is a 10 mm-diameter REBCO cable for 3 kA currents at 60 K.

kA currents Delivery and handling of the 120 kA MqB, cable assembly. The flexible, double-walled corrugated cryostat comprises 19 MqB, superconducting cables in a single assembly, twisted together to form a compact bundle. Each MqB, cable is about 140 m long with the bundle diameter around 90 mm.

when series procurement of the wire was launched. In par- needed for the HL-LHC have been produced. allel, different cable layouts were developed and validated at CERN. This included round MgB, cables in a co-axial con- conducting system, but the system itself requires a global figuration rated for 3kA and for 18kA at 25K (see "Complex optimisation, which is achieved via an integrated design. cabling" figure). While the prototypes made at CERN were 20 Following this approach, the challenge was to investigate characteristics to enable production via industrial cabling the superconducting links with enhanced cryogenic perof the superconductor, and are of key importance for the of the system, improves the mechanical flexibility of the reliability of the final system.

The first qualification at 24 K of a 20 kA MgB₂ cable protogether, took place in 2014. This followed the qualification at CERN of short-model cables and other technological aspects, as well as the construction of a dedicated test place at Cryoworld in the Netherlands. station enabling the measurement of long cables operated in 2018. Final prototype cables of the type needed for the tion (see "kA currents" image). The challenge of dealing

required electro-mechanical characteristics was produced. HL-LHC (for both the triplets and matching sections) were The next step was to manufacture long unit lengths of validated at CERN in 2020, when series production of the MgB₂ wire via larger billets (the assembled composite rods final cables was launched. As of today, the full series of about that are then extruded and drawn down in a long wire). The 1450 km of MgB₂ wire - the first large-scale production target unit length of several kilometres was reached in 2018 of this material – and five of the eight final MgB, cables

Superconducting wire and cables are the core of a superto 30 m long, the cable layout incorporated, from the outset, and develop, in industry, long and flexible cryostats for machines of the type used for conventional cables. Splice formance. The goal was to achieve a low static heat load techniques as well as detection and protection aspects were (<1.5W/m) into the cryogenic volume of the superconducting addressed in parallel with wire and cable development. Both cables while adopting a design - a two-wall cryostat without technologies are strongly dependent on the characteristics intermediate thermal screen - that simplifies the cooling links and eases handling during transport and installation. This development, which ran in parallel with the wire duced at CERN, comprising two 20 m lengths connected and cable activities, led to the desired results and, after an extensive test campaign at CERN, the developed technology was adopted. Series production of these cryostats is taking

The optimised system minimises the cryogenic cost for at higher temperatures, in a forced flow of helium gas. The the cooling such that a superconducting link transfers cables were then industrially produced at TRATOS Cavivia from the tunnel to the technical galleries - just enough a contract with ICAS, in a close and fruitful collaboration helium gas to cool the resistive section of the current leads that enabled – while operating heavy industrial equipment and brings it to the temperature (about 20 K) for which the - the requirements identified during the R&D phase. The leads are optimised. In other words, the superconducting complexity of the final cables required a multi-step process link does not add cryogenic cost to the refrigeration of the that used different cabling, braiding and electrically insu-system. The links, which are rated for currents up to 120kA, lating lines, and the implementation of a corresponding are sufficiently flexible to be transported, as for conventional quality-assurance programme. The first industrial cables, power cables, on drums about 4 m in diameter and can be which were 60 m long, were successfully qualified at CERN manually pulled, without major tooling, during installa-

38

CERNCOURIER

CERN COURIER MAY/IUNE 2023

CERN COURIER MAY/IUNE 2023

39

FEATURE SUPERCONDUCTIVITY

End of the line Crvostat termination of the superconducting link with the HTS current leads integrated. The total length is about 5.5 m.

(Credit: CERN)

with the thermal contraction of the superconducting links, which shrink by about 0.5 m when cooled down to cryogenic temperature, was also addressed. An innovative solution, which takes advantage of bends and is compatible with the fixed position of the current lead cryostat, was validated with prototype tests.

Novel HTS leads

4.5K liquid helium environment in the LHC tunnel to about 20 K in the HL-LHC new underground galleries, a different superconducting material is required to transfer the current from 20 to 50 K, where the resistive part of the current leads makes the bridge to room temperature. To cope with the system requirements, novel HTS current leads based on REBCO (rare-earth barium copper oxide) HTS superconducting tape - a material still in a development phase at the time of the LHC study – have been conceived, constructed and qualified to perform this task (see "Bridging the gap" image). Compact, round REBCO cables ensure, across a short ILC, where the adoption of flexible powering lines can sim-(few-metre-long) length, the electrical transfer from the MgB₂ to 50 K, after which the resistive part of the current leads finally brings the current to room temperature. In view of the complexity of dealing with the REBCO conductor, the An enabling technology corresponding R&D was done at CERN, where a complex dedicated cabling machine was also constructed.

While REBCO tape is procured from industry, the challenges encountered during the development of the cables were many. Specific issues associated with the tape conductor, for example electrical resistance internal to the tape and the dependence of electrical properties on temperature and cycles applied during soldering, were identified and solved with the tape manufacturers. A conservative approach imposing zero critical current degradation of the tape laid underground with reduced footprints. after cabling was implemented. The lessons learnt from this development are also instrumental for future projects employing REBCO conductors, including the development of high-field REBCO coils for future accelerator magnets.

The full series of about 1450 km of MgB₂ wire and five of the eight MgB₂ final cables needed for the HL-LHC have now been produced

60 m-long superconducting lines of the type needed for the LHC triplets and for the matching sections, both in 2020. The complex terminations of the superconducting links involve two types of cryostat that contain, at the 20 K side, the HTS current leads and the splices between REBCO and MgB₂ cables and, at the 4.2K side, the splices between the niobium titanium and the MgB₂ cables. A specific development in the design was to increase compactness and enable the connection of the cryostat with the current leads to the superconducting link at the surface, prior to installation in the HL-LHC underground areas (see "End of the line" figure). The series production of the two cryostat terminations is taking place via collaboration agreements with the University of Southampton and Uppsala University. The displacement of the current leads via the adoption of superconducting links brings a number of advantages. These include freeing precious space in the main collider ring, which becomes available for other accelerator equipment, and the ability to locate powering equipment and associated electronics in radiation-free areas. The latter Whereas MgB₂ cables transfer high DC currents from the relaxes radiation-hardness requirements for the hardware and eases access for personnel to carry out the various interventions required during accelerator operations.

Cooling with low-density helium gas also makes electrical transfer across long vertical distances feasible. The ability to transfer high currents from underground tunnels to surface buildings - as initially studied for the HL-LHC - is therefore of interest for future machines, such as the proposed Future Circular Collider at CERN. Flexible superconducting links can also be applied to "push-pull" arrangements of detectors at linear colliders such as the proposed CLIC and plify and reduce the time for the exchange of experiments sharing the same interaction region.

Going beyond fundamental research in physics, superconductivity is an enabling technology for the transfer of GWs of power across long distances. The main benefits, in addition to incomparably higher power transmission, are small size, low total electrical losses, minimised environmental impact and more sustainable transmission. HTS offers the possibility of replacing resistive high-voltage overhead lines, operated across thousands of kilometres at voltages reaching about 1000 kV, with lower voltage lines,

Long-distance power transmission using hydrogencooled MgB₂ superconducting links, potentially associated with renewable energy sources, is identified as one of the leading ways towards a future sustainable energy system. The series components of the HL-LHC cold-powering Since hydrogen is liquid at 20 K (the temperature at which systems (superconducting links with corresponding ter- MgB, is superconducting), large amounts can be stored minations) are now in production, with the aim to have all and used as a coolant for superconducting lines, acting systems available and qualified in 2025 for installation in at the same time as the energy vector and cryogen. In the LHC underground areas during the following years. this direction, CERN participated - at a very early stage Series production and industrialisation were preceded by the of the HL-LHC superconducting links development - in completion of R&D and technological validations at CERN. a project launched by Carlo Rubbia as scientific direc-Important milestones have been the test of a sub-scale 18kA tor of the Institute for Advanced Sustainability Studies superconducting link connected to a pair of novel REBCO (IASS) in Potsdam. Around 10 years ago, CERN and IASS current leads in 2019, and the test of full-cross section, joint research culminated in the record demonstration

of the first 20kA MgB, transmission line operated at liq-strator of superconducting distribution in aircraft called a monopole MgB, cable system operated in helium gas at was recently launched at CERN. 20 K. This was qualified in industry for 320 kV operation technology (see CERN Courier January/February 2023 p9).

development of high-performance, low-cost, sustainable and environmentally friendly energy storage and production systems is a key challenge for society. The use of hydro-

uid hydrogen temperature. This activity continued with SCALE (Super-Conductor for Aviation with Low Emissions), a European initiative called BestPaths, which demonstrated which uses the HL-LHC superconducting link technology,

CERN's developed experience in superconducting-link and at 10 kA at CERN, proving 3.2 GW power transmission technology is also of interest to large data centres, with a capability. This initiative involved European industry and collaboration agreement between CERN and Meta under France's transmission system operator. In Italy, the INFN discussion. The possibility of locating energy equipment has recently launched a project called IRIS based on similar remotely from servers, of transferring efficiently large power in a compact volume, and of meeting sustainabil-In addition to transferring power across long distances ity goals by reducing carbon footprints are motivating a with low losses and minimal environmental impact, the global re-evaluation of conventional systems in light of the potential of superconducting transmission.

Such applications demonstrate the virtuous circle The use of between fundamental and applied research. The requiregen can diversify energy sources as it significantly reduces ments of fundamental exploration in particle physics greenhouse-gas emissions and environmental pollution research have led to the development of increasingly during energy conversion. In aviation, alternative-propulsion powerful and sophisticated accelerators. In this endeavsystems are studied to reduce CO, emission and move toward our, scientists and engineers engage in developments zero-emission flights. Scaling up electric propulsion to larger initially conceived to address specific challenges. This aircraft is a major challenge. Superconducting technologies often requires a multi-disciplinary approach and collaboare a promising solution as they can increase power density ration with industry to transform prototypes into mature in the propulsion chain while significantly lowering the technology ready for large-scale application. Accelerator mass of the electrical distribution system. In this context, a technology is a key driver of innovation that may also pollution collaboration agreement has recently been launched between have a wider impact on society. The superconducting-link during energy CERN and Airbus UpNext. The construction of a demon-system for the HL-LHC project is a shining example.

hydrogen can diversify energy sources as it significantly reduces greenhouse-gas emissions and environmental conversion

Fabricated copper products for high energy physics applications

Luvata offers oxygen-free copper products in many shapes and sizes. OFE, CuAg and CuCrZr alloys are also available for demanding applications in the world of physics.

www.luvata.com

IOP Publishing

40

CERNCOURIER VOLUME 63 NUMBER 3 MAY/JUNE 2023

CERN COURIER MAY/IUNE 2023

CERN COURIER MAY/IUNE 2023